

## INTENDED USAGE

---

This product is designed for use in small spaces to protect items from damp and moisture. Examples include shoe cabinets, wardrobes, bookcases, cupboards, jewellery boxes, CD cabinets, pianos, food cabinets and more. For larger spaces, please use the ProBreeze 500ml (1100 Cubic Feet) or 1500ml (2200 Cubic Feet) dehumidifier.



Keep your personal electronics safe and dry



Moisture-proof food and perishables



Maintain a dry and damp-free wardrobe



Keep your personal belongings safe and dry

---

## FEATURES

- 1 Body
- 2 Indicator
- 3 Moisture Absorbing holes
- 4 Charging indicating light
- 5 Plug (back)



Voltage | AC100-240V 50/60Hz  
Power | 20W  
Hygroscopic Capacity |  $\approx$  150ml (9 cubic inches)

Net Weight | 0.40kg (14 ounces)  
Size | W165 x D102 x H43 (mm)  
W 6.7 x D 4.3 x H 1.8 (inches)

# ProBreeze

Rechargeable Mini Dehumidifier

# USER MANUAL

## INSTRUCTIONS

---

1. If the indicator is dark green before first use, plug in the device and recharge for 12-15 hours. When the crystal indicator has changed from green to orange, the mini dehumidifier is ready for use.



photo 1

2. Once the indicator is orange (photo 1), place the dehumidifier into the location you wish to keep free from moisture (e.g. Wardrobe, Cupboard, Jewellery Box)

3. When the dehumidifier has filled with moisture the crystal indicator will turn from orange to green. Remove the dehumidifier and connect the power cord to the back (photo 2/3). The charging light will turn on to indicate that the dehumidifier is in recharging mode and releasing moisture. (photo 4)



photo 2

4. After 12-15 hours, the crystals will change back from green to orange indicating that the stored moisture has been removed and the dehumidifier is recharged.

\*Note: Please keep on charging for a few extra hours if the indicator hasn't completely changed back after 15 hours.



photo 3

5. Remove the power adaptor to end recharging.

6. The mini dehumidifier is ready for use once again.




photo 4

---

## SAFETY WARNINGS

- The moisture absorption speed is not the same in different environments. Humidity and temperature will especially influence the speed of the indicator color changing.
- The surface will become warm when recharging. Keep away from flammable objects.
- Keep all objects at least 10cm (4 inches) away to increase air convection.
- It is normal to see steam on the indicator when the unit is releasing moisture.
- In order to avoid damage or leakage, do not soak in water.
- Do not use in conjunction with medical products.
- Keep away from fire, gas stoves and other flammable places.
- If the plug is damaged, do not use and contact manufacturer for replacement.
- If the unit is broken or damaged stop using and remove from power supply immediately.